

WEIGHING:

Time to Connect Your Scale



(1) Turn your console on and press "TRANSMIT".



(2) Note the a wireless symbol will appear and will be blinking.

(3) Go to your Android device and tap Wrestler Weigh In on the slide menu.



(4) Your Android device should now read "CONNECTED" and the wireless symbol on your console should no longer be blinking, (see step 2 for wireless icon).

(5) If your Android is Reading "Not Connected", tap on the Not Connected and it will now read Connected.



(6) For Weight Allowance tap Yes, or tap to read NO. For Official weigh-in tap unofficial to read official for both practice and tournament weigh-ins.