

BEFOUR

PRECISION SCALES

OFFICIAL SCALE OF POP WARNER

Specifically designed for youth football programs...

Model PS-6700PW Portable Battery Powered Scale



Proudly Made in the USA



Save Time-Condense Weigh-ins to a Single Set Up!!!

Pass/Fail Display

Weigh-in 6 to 8 players per minute on average! Programmable certification weight ranges allow a user to input minimum and maximum allowable weights. Readout will display the PASS or FAIL result within seconds of stepping on the platform. View the numeric weight at any time with the press of a button. A programmable equipment allowance will automatically deduct the weight for uniformed players if needed.



Ultimate in Accuracy

Be certain your players meet their weight classifications, The PS-6700PW has an accuracy to within 1/10 lb.

Extended Battery Life

The PS-6700PW operates on (6) six C-cell alkaline batteries. With regular use the batteries are guaranteed to last over two full seasons! Battery life is indicated on the readout console.



Rugged and Portable Design

Durable, yet light weight and mobile, the PS-6700PW can be conveniently transported in one of two optional carrying cases .

MODEL PS-6700 PW

Platform Dimensions	16" x 18" x 1 3/4"
Weight Capacity	500 lbs. or 225 kg.
Accuracy / Resolution	± 0.1 lb. (± 0.1 kg.)
Power Source	6 C-cell batteries
Readout	1" LCD digits
System Weight	15 lbs.
Warranty	3 Years

Model SC-1816 Soft-Sided Carry Case



Padded nylon soft case. Safely stores scale platform, readout console, and cables. Great for storage, protection and transport

Model HC-1825 Hard-Shell Carry Case



Heavy-duty polyethylene hard-shell case with custom-cut foam interior is designed for added safety during transport

OPTIONAL CARRY CASES:

Befour Inc.
 102 Progress Drive Phone Web Fax E-mail
 Saukville, WI 53080 800-367-7109 www.befour.com 262-284-5966 sales@befour.com

