

BEFOUR

SPORTS & FITNESS SCALES

Free Standing Battery-Powered Scale with BMI

Model FS-0961

With its simple, straightforward design, the FS-0961 provides fast weight measurements in a sleek yet durable constructed scale. Battery power allows user to place this scale anywhere—no outlet or re-charging needed! Efficient design allows batteries to last over 80,000 weighings. Weight measurement is quick: 2 seconds under normal use, plus one button weight recall and reweigh in either pounds or kilograms. Stand-on scales like the FS-0961 are ideal for locker rooms, fitness clubs, and personal use.

FEATURES & BENEFITS:

Body Mass Index:


Dual-mode BMI calculator allows user-or assistant-operation and provides a quick and easy BMI calculation, programmable clothing allowance built-in

Push Button Calibration:

Set calibration via keypad entry without the need of tools

Rugged and durable all-metal construction

Large platform for greater stability

 Accurately calculates the weight of an unsteady user



DISPLAY CONSOLE FEATURES



- Displays weight, height, and BMI
- **Programmable User Settings:** can be set to auto-off (12 sec. to 25 min.), always-on, etc.
- **LB/KG Lockout:** Change setup to display only your desired unit of measure
- 3-segment battery life indicator
- Large 1" easy-to-read digits on LCD screen
- No AC outlet or recharging needed (batteries last all season)
- Auto zero, recall, and reweigh
- Audible sound indicates weight is "locked in"

SPECIFICATIONS:

Scale Height.....	42"
Platform Dimensions.....	16" x 18" x 1 3/4"
System Weight.....	17 lbs
Resolutions.....	0.1 lb (0.05 kg)
Accuracy.....	± 0.1 lb (0.05 kg)
Power Source.....	4 D cell Alkaline Batteries
Battery Life.....	80,000 weighings
Display Readout.....	1" LCD digits
Warranty.....	3 years



Befour, Inc.

102 Progress Drive · Saukville, WI 53080 · P: 800-367-7109 · F: 262-284-5966
Befour.com · sales@befour.com